

## **ALL SUPERKLEAN PARTS ARE INTERCHANGEABLE WITH THOSE OF OUR COMPETITORS**

SuperKlean spray nozzles were designed for long lasting durability and to withstand abuse common in industrial environments. Due to regular wear and tear, our engineers used simplicity as a key factor in the design of our nozzles. SuperKlean's nozzle are considered one of the few nozzles in the sanitation equipment industry to be truly "user friendly". Especially when repairs or replacements have to be made.

### **The following are instructions for replacement of internal components:**

1. Remove nozzle cover through the back of nozzle.
2. Remove lever screw and pull lever out.
3. Unscrew lock screw and pull out barrel assembly from back end of nozzle with cage.
4. To insert a new barrel assembly, reverse above procedure.
5. When replacing cage, cut-away part of cage should be facing downward.
6. Be sure that the lever arm is placed ahead of retractor rod on barrel assembly.

